

Installation Manual for the F-Line underground tank RAIN ACTIV SYSTEM ONLY

1,500 litre 3,000 litre 5,000 litre 7,500 litre





Rainwater Harvesting Limited, Unit A Harrier Park, Southgate Way, Orton Southgate, Peterborough, PE2 6YQ,UK Phone +44 (0) 1733 405111 – Fax +44 (0) 1733 230996 Email : <u>info@rainwaterharvesting.co.uk</u> – Website : <u>www.rainwaterharvesting.co.uk</u> 25th April 2019



Tank Dimensions and inverts

With the tank you will have received one of three different shafts dependent on your order. Please note which has been received and refer to the relevant shaft in the grid below :

- VS20 235mm shaft and pedestrian lid
- VS60 635mm shaft and pedestrian lid The overall height difference below is because up to 400mm can be cut off the 635mm shaft on site so as to achieve your exact invert level
- Driveable shaft & lid Steel lid and shaft for vehicle loading

| | 1500 L | 3000 L | 5000 L | 7500 L |
|--|--|-------------|--------------|-------------|
| | | | | |
| Weight KG | 80 | 170 | 250 | 310 |
| Length | 2400 | 2400 | 2960 | 3340 |
| Width | 1200 | 2400 | 2220 | 2310 |
| | | | | |
| Overall Height (VS20 – 235mm shaft) | 1015 | 1015 | 1350 | 1415 |
| Overall Height (VS60 – 635mm shaft) | 1015 – 1415 | 1015 – 1415 | 1350 – 1750 | 1415 – 1815 |
| Overall Height (Driveable shaft and lid) | 1415 | 1415 | 1750 | 1815 |
| | | | | |
| Ground to Invert (VS20 – 235mm shaft) | 320 | 320 | 345 | 310 |
| Ground to Invert (VS60 – 635mm shaft) | 320 – 720 | 320 – 720 | 345 – 745 | 310 – 710 |
| Ground to Invert (Driveable shaft & lid) | 720 | 720 | 745 | 710 |
| | | | | |
| Minimum Attenuation Volume | SUBJECT | TO MICRO DR | AINAGE CALCU | JLATIONS |
| | | | | |
| Invert to Outlet | SUBJECT TO MICRO DRAINAGE CALCULATIONS | | | |

Excavation

| | 1500 L | 3000 L | 5000 L | 7500 L |
|---------------------------------------|-------------|-------------|-------------|-------------|
| | | | | |
| Length | 2800 | 2800 | 3360 | 3740 |
| Width | 1600 | 2800 | 2620 | 2710 |
| | | | | |
| *Overall Height VS20 | 1115 | 1115 | 1450 | 1515 |
| *Overall Height VS60 | 1115 – 1515 | 1115 – 1515 | 1450 – 1850 | 1515 – 1915 |
| *Overall Height Driveable shaft & lid | 1515 | 1515 | 1850 | 1915 |

*The overall excavated height allows for a base of 100mm compacted aggregate

Please check your outlet levels carefully, details can be found on page 2 of your proposal, if the outlet cannot connect to the drains so the system discharges by gravity you will require a pumping station (which we do not supply)

Rainwater Harvesting Limited, Unit A Harrier Park, Southgate Way, Orton Southgate, Peterborough, PE2 6YQ,UK Phone +44 (0) 1733 405111 – Fax +44 (0) 1733 230996

Email : <u>info@rainwaterharvesting.co.uk</u> – Website : <u>www.rainwaterharvesting.co.uk</u> 25th April 2019



1. Location

1.1 Position to the building

- The excavation must not be within the minimum distance to the building. See Image 1.
- The tank may not be built over by any loads greater than vehicle loads.



1.2 Traffic Conditions

- Loading Class A15 e.g pedestrian or cyclist The standard pedestrian lid is suitable.
- Loading Class B e.g car, minibus, max axle load of 2.2 tonnes Vehicle loading shaft and lid required. Minimum distance from top of tank body to earth surface must be 600mm

1.3 Ground conditions

• The tanks may lie in ground water and / or surface water up to the top of the body of the tank. Please refer to the table below to see the maximum depth dependent on your tank and shaft type.

| | 1500 L | 3000 L | 5000 L | 7500 L |
|---|-----------|-----------|-----------|-----------|
| | | | | |
| Max water table depth (VS20 – 235mm shaft) | 365 | 365 | 430 | 290 |
| Max water table depth (VS60 – 635mm shaft) | 365 - 765 | 365 – 765 | 430 - 830 | 290 - 690 |
| Max water table depth (Driveable shaft & lid) | 765 | 765 | 830 | 690 |

1.4 Hillside location

- The soil within the area where the tank is to be positioned must be checked for possible soil movement (DIN 1054 edition 1/2003, E DIN 4084 edition 11/2002) and if necessary will need to be secured with a supporting structure (eg retaining wall)
- Consultation with local authorities is recommended.

Rainwater Harvesting Limited, Unit A Harrier Park, Southgate Way, Orton Southgate, Peterborough, PE2 6YQ,UK Phone +44 (0) 1733 405111 – Fax +44 (0) 1733 230996

Email : info@rainwaterharvesting.co.uk – Website : www.rainwaterharvesting.co.uk 25th April 2019



1.5 Installation details

1.51 In clay ground conditions:

• The excavated area should be wide enough to allow the compression of the filling material (200mm) See Image below.



- With installations deeper than 1.75m (ground to base of tank) use 500mm width of the filling material.
- The tank should be covered with at least 300mm of filling material.

1.52 In loose ground conditions:

- Up to 1.75m depth of excavation use 200mm of filling material around the sides of the tank.
- With installations deeper than 1.75m use 500mm width of the filling material
- The tank should be covered with at least 300mm of filling material

1.6 Further criteria

- Existing pipelines, pipes, vegetation and other specifics must be considered so that damage or hazards will be avoided.
- The maximum soil coverage on top of the tank body is 1.5m
- If it is not guaranteed that the ground water level will remain below the permitted maximum level, a drainage system must be installed around the tank, which reliably drains the water. If a drainage system is not possible then contact your supplier about an alternative tank.



Rainwater Harvesting Limited, Unit A Harrier Park, Southgate Way, Orton Southgate, Peterborough, PE2 6YQ,UK Phone +44 (0) 1733 405111 – Fax +44 (0) 1733 230996

Email : info@rainwaterharvesting.co.uk – Website : www.rainwaterharvesting.co.uk

25th April 2019



2. Installation

2.1 Backfill around and below the tank

• Backfill material around the tank has to be well compacted and permeable to water allowing close packing and no damage to the surface of the tank

• If the filling material contains sharp of sharp-edged components, the wall of the tank must be protected by a sandy coating.

2.1.1

• Gravel mixtures are the preferred filling material. The recommended sizes 8mm-16mm

2.1.2

- Concrete gravel with a particle size of up to 16mm is recommended for use in clay / loam soil conditions with ground water and high water table.
- When ground water and a high water table are present it is important to ensure good compaction when applying the filling material.

2.1.3

 Stone Chippings – crushed rock particles between 4mm and 16mm in size are suitable filling material. However due to the sharp edges the tank must be protected against damage, for example using a sand coating.

2.1.4

• Excavation – sand and gravel mixtures with mixed particle sizes is suitable as a filling material providing they meet the criteria listed under 2.1

2.1.5

• Top soil, clay, loam and other types of cohesive soils are not suitable as filling material.

2.2 Backfill on top of the tank

• Excavated soil or other material can be used if it is stable and permeable

2.3 Backfilling and compaction methods

• The backfilling and compaction methods to be used are described in Section 3 (Installation Instructions) 2.3.1

- Adding water to the filling material is not recommended as this will make the compacting unstable
- The base layer for driveable situations must use a grain size of 2/45

2.4 Pipes

2.4.1

- The feed pipe should be laid with a fall to the tank of greater than 1 degree
- Ensure that underground rainwater pipes come from sealed gullies (do not use open gullies)

2.4.2

• The overflow pipe / drain pipe should have a deeper fall away from the tank than the fall from the feed pipe to the tank

2.4.3

• The service pipe is to be installed using the provided seals to ensure a tight fixture to avoid contaminants entering the tank. All electrical and other cables are laid through this service pipe back to the property.

Rainwater Harvesting Limited, Unit A Harrier Park, Southgate Way, Orton Southgate, Peterborough, PE2 6YQ,UK Phone +44 (0) 1733 405111 – Fax +44 (0) 1733 230996

Email : info@rainwaterharvesting.co.uk – Website : www.rainwaterharvesting.co.uk



- 2.4.4
- The pipes must be laid in such a way to avoid frost damage.

3. Installation Instructions

- 1. Establish distance from the property.
- 2. Dig hole





3. Lay 100mm base



4. Compact the base by hand only. Ensure you have a level base.



Rainwater narvesting Limited, omt A marner Fark, Southgate way, Onon Southgate, Peterborough, PE2 6YQ,UK Phone +44 (0) 1733 405111 – Fax +44 (0) 1733 230996 Email : info@rainwaterharvesting.co.uk – Website : www.rainwaterharvesting.co.uk 25th April 2019



5. Lower the tank carefully into the hole ensuring that you are achieving the necessary widths around the tank for the filling material.



6. Fill the tank with water up to half way



7. Apply filling material



- Do not use a mechanical

- minimum width between the tank and excavation wall is correct (min 200mm)



8. Hand compress the filling material into the central columns



To link tanks together do the following:

- Drill a hole using a 127mm drill bit into a flat part of the tank at low level.
- Insert the supplied grommets (seals) into the hole.
- Feed a 4" pipe into the hole allowing at least 500mm to be inside of the tank.
- Use washing up liquid if necessary to assist with pushing the pipe through the grommet.

NOTES :

• Please refer to the individual installation documents for the shafts, extension sleeve and driveable shaft and lid.



Tank dimensions and hole positions

Please note for the Rain Activ tanks you must refer to your specific proposal which will give you the height of the overflow (outlet) hole marked as 'C' on the drawings. If in doubt please call 01733 405104.







Rainwater Harvesting Limited, Unit A Harrier Park, Southgate Way, Orton Southgate, Peterborough, PE2 6YQ,UK Phone +44 (0) 1733 405111 – Fax +44 (0) 1733 230996 Email : <u>info@rainwaterharvesting.co.uk</u> – Website : <u>www.rainwaterharvesting.co.uk</u> 25th April 2019





Rainwater Harvesting Limited, Unit A Harrier Park, Southgate Way, Orton Southgate, Peterborough, PE2 6YQ,UK Phone +44 (0) 1733 405111 – Fax +44 (0) 1733 230996 Email : <u>info@rainwaterharvesting.co.uk</u> – Website : <u>www.rainwaterharvesting.co.uk</u> 25th April 2019



